# **LED Lighting Control System Instruction Manual**



### Attentions:



Read the instruction carefully before installation , non-observance of this instruction may cause damage to the fixture or hurt to human body .The installation must be carried out by a qualified electrician in accordance with national or local codes .

Cut off the power supply before installation and maintenance!


Regularly check the controller ,sensor ,the cord and other accessories .

If any part is damaged, the product should not be used.

Keep this instruction manual handy for future use .

The production is only for indoor and dry location.

#### Use only with SELV driver according EN 61347-2-13.



Art. No.	Rated supply	Rated load	Та
539 490 01	12VDC	30W	-20℃ 35℃
539 490 51	24VDC	60W	-20 ( 35 (


#### **Features**


- 1. DC 12V/24V input
- 2. 6-way DC output
- 3. Work with max. 3 switches or sensors
- 4. Adjustable motion sensor delay time: 5~120s
- 5. Memory function
- 6. Two or more control boxes can be connected with each other to increase the number of sensors and output.
- 7. All lights can be controlled at the same time by any sensor when using more than one control box.

#### **Function Definition**

- 1. ON/OFF sensor Turn ON and OFF.
- 2. Dimmer sensor Turn ON and OFF, dimming 10-100%.
- 3. Door/Drawer sensor Open the door or drawer >50mm to turn on the light, close the door or drawer <50mm to turn off the light.
- 4. PIR sensor When human-body moves in the detection range(0~3m), light will turn on, when human-body leaves the detection range or no motion detected in the detection range, light will turn off after delay time.

### **Application**







In multi-control mode, you can connect up to three door sensors max., these three door sensors must be connected by one control box, otherwise it will be malfunction.









Screwdriver


Driller


Ø20mm Hole opener

Ø12mm Hole opener


Φ12 Recess Mounted Sensor
539.489.01
539.489.02
539.489.03
539.489.41
539.489.42








Surface	Mounted Sensor
5	39.489.11
5	39.489.12
5	39.489.13
5	39.489.21
5	39.489.22



Symbol	
(Zhm)	Touch ON_OFF Switch
(F)	Touch Dimming Switch
(((4)	IR ON_OFF Switch
((((4)	IR Dimming Switch
	IR Door Switch

#### **IR Recessed Sensor**

#### Dimension in mm




Art. No.	Description	Detection	Standby	Consumption	Drilling
Art. No.	Description	Range	Power	Power	Hole
539 489 01	IR ON/OFF Sensor	0~50mm	< 0.05W	< 0.1W	Φ12
539 489 02	IR ON/OFF + Dimmer Sensor	0~50mm	< 0.05W	< 0.1W	Ф12
539 489 03	IR Door/Drawer Sensor	0~50mm	< 0.05W	< 0.1W	Φ12



- 1. Objects for blocking the induction must be non-black and clear glass, otherwise it doesn't work.
- 2. Must be used in detection range.

#### **IR Surface Mounted Sensor**

#### Dimension in mm




Art. No.	Description	Detection	Standby	Consumption	symbol
Art. No.	Description	Range	Power	Power	Syllibol
539 489 11	IR	0~50mm	< 0.05W	< 0.1W	(((d
559 469 11	ON/OFF Sensor	0~3011111	< 0.03VV	< 0.1VV	
539 489 12	IR	0~50mm	< 0.05W	< 0.1W	((((d
559 469 12	ON/OFF + Dimmer Sensor	0~30mm	< 0.05VV	~ O. 1VV	
539 489 13	IR	0~50mm	< 0.05W	< 0.1W	))
339 469 13	Door/Drawer Sensor	0~3011111	~ 0.05VV	~ U. IVV	



- 1. Objects for blocking the induction must be non-black and clear glass, otherwise it doesn't work.
- 2. Must be used in detection range.

# **Touch Surface Mounted Sensor**


## Dimension in mm



Art. No.	Description	Standby Power	Consumption Power	symbol
539 489 21	Touch ON/OFF Sensor	< 0.03W	< 0.05W	Elm
539 489 22	Touch ON/OFF + Dimmer Sensor	< 0.03W	< 0.05W	(E)


## **Push Switch**

## Dimension in mm



Art. No.	Description	Drilling Hole
539 489 41	ON/OFF Push Switch	Ф12
539 489 42	ON/OFF + Dimmer Push Switch	Ф12


#### Dimension in mm




Art. No.	Description	Detection	Standby	Consumption	Drilling
Art. No. Descript		range	Power	Power	Hole
539 489 31	PIR Sensor	0~3000mm	< 0.3W	< 0.5W	Ф 20

#### **Function**

- 1. First conneding to power supply, the PIR sensor no detect for about 10s then starts to work.
- 2. Delay time adjust by control box.



- 1. Top installation
- 2. Side installation
- Good Sensivity
- 3. Poor Sensivity



\_\_\_\_more sensors are designing\_\_\_\_



